



Impressa F50 Quick Reference Maintenance Guide



Please note This Guide does not replace the Operating Instructions. For details and cautions you must read all instructions.

 **NOTE:** The *Maintenance* Key has the following symbol

 *ON / OFF* Key has the following symbol

Cleaning (duration: approx. 15 mins)

When the machine is displaying Display text: **READY / CLEAN**

- Press *maintenance* key down until the display shows **EMPTY / TRAY**
- Remove and empty drip and grounds tray and place back into the machine
- Place a receptacle (approx. 1 litre) under the coffee spout
- Press *maintenance* key
- Machine will Display text: **ADD / TABLET**
- Open funnel cover (see left)
- Drop in JURA cleaning tablet and close cover
- Press *maintenance* key
- Machine will start process
- Display text: **EMPTY / TRAY**
- Empty drip and grounds tray and place back into the machine
- Wipe out filler funnel for ground coffee with a dry cloth after the cleaning program has finished.



Changing the filter (duration: approx 5 mins)

After 50 litres of water or after 2 months the filter cartridge needs replacement.

- Display text: **READY / FILTER**
- Switch machine off using the *ON / OFF* key on front panel
- Press *maintenance* key until **CHG FILTER / OPEN TAP** displayed
- Remove and empty water tank
- Flip up cartridge holder (1)
- Remove old **CLARIS** filter cartridge from tank and return to Quaffee
- Place new filter cartridge (2) into water tank, applying slight pressure
- Close cartridge holder (1) (engages with a click)
- Fill water tank and place back into machine
- Place a receptacle (at least 0.5 litre) under Easy-Auto-Cappuccino Frother
- Turn tap to steam position
- Turn tap to initial position when **CLOSE / TAP** display prompts you to do so



Decalcifying (duration: approx. 60 mins)

- Display text: **DECALCIFY**
- Switch machine off using the *ON / OFF* key
- Hold maintenance key down until the display shows **EMPTY / TRAY**
- Empty drip and grounds tray and place back into machine
- Carefully remove the Easy-Auto-Cappuccino Frother
- **SOLVENT / IN TANK** is displayed
- Remove water tank and empty it
- Completely dissolve contents of a blister (3 tablets) in 0,5 litres of water
- Pour solution into the empty water tank
- Place water tank back into machine
- Place a receptacle (at least 0.5 litre) under the spout
- Turn tap to steam position
- **DECALC.ON** is displayed



- When **CLOSE / TAP** displayed turn tap to the initial position. It now cleans the inside of the machine
- **EMPTY / TRAY** is displayed. Empty drip tray and reinsert
- **FILL / WATER** is displayed. Rinse water tank well, fill with cold fresh tap water place it back into machine
- **OPEN / TAP** displayed
- Place receptacle under spout
- Turn tap to steam position
- When **CLOSE / TAP** displayed turn the tap back to the initial position
- **EMPTY / TRAY** displayed
- Empty drip tray and reinsert
- Reassemble the Easy-Auto-Cappuccino Frother
- Shift receptacle under height-adjustable coffee spout
- Press maintenance key